

# 2014i Emergency Vehicle EPA Relief Provisi

- GM Solution: Allow maximum EPA warning range and speed restriction relaxation

2012+MY SCR Warning Strategies				
Strategy	Warning Only	65 mph	55 mph	4 mph
	miles	miles	miles	miles
SCR system <b>Tamper</b>	100	75	75	infinite
DEF <b>Quality</b>	100	75	75	infinite
DEF <b>Level</b>	400	75	75	infinite
SCR system <b>Fault</b>	175	75	infinite	
EGR system <b>Fault</b>	175	75	infinite	

2014i Emergency Vehicle Warning Strategies				
Strategy	Warning Only	65 mph	55 mph	4 mph
	miles <sup>1</sup>	miles	miles	miles
SCR system <b>Tamper</b>	620	580	75	infinite
DEF <b>Quality</b>	620	580	75	infinite
DEF <b>Level</b>	620	580	75	infinite
SCR system <b>Fault</b>	remove			
EGR system <b>Fault</b>				

1. 24 hours allowed by EPA => 1,200 miles Max DIC value 999km = 620 miles